

## Taking care of your LWA Unit

### Use of Charger

When not in use, the unit should be placed on charge.

#### To charge

1. Plug mini HDMI into the side of the unit – DO NOT FORCE IT.
2. Plug the USB lead into the GPO plug provided
3. Plug the plug head into a suitable power outlet
4. Ensure outlet is turned on.

The LED's should flash for short period to indicate connection, then only RED will stay solid while unit is charging.

Do not attempt or use any other charger unit to charge the LWA device other than the charger issued with this device.

